


Selection guide

Fuse protection

Which
application?

Type of
operation?

Industry						
						
<i>FUSERBLOC BS88/NFC/DIN</i>	<i>FUSERBLOC DRIVE</i>	<i>FUSOMAT DIN SIDERMAT DIN</i>	<i>RM - RMS</i>	Fuse bases	Industrial fuses BS88/NFC/DIN	
20 to 1250 A	125 to 1600 A	250 to 1800 A	32 to 125 A	160 to 2500 A	0.16 to 1250 A	
Applications						
Transformer output			•			•
Section connectors				•	•	•
Cabinet entrance	•	•	•			•
Wiring						•
Motor circuits	•	•	•			•
Semi-conductor protection				•	•	
Photovoltaic installations						
Device operation						
Manual	•	•	•			
Via tripping			•			
Location of manual handle						
Front		•	•			
Side		•	Up to 1250 A			
Via a panel						
Location of external handle						
Front	•		•			
Right side	•		Up to 1250 A			
Left side	contact us					
Central	contact us					
Breaking						
Fully visible	•	•	•			
Visible			•			
Fuses						
BS88	•	•		•		•
NFC/DIN	•	•	•		•	•
UL	see UL catalogue	see UL catalogue				•
Other						

[illegible]